



FP-22B FLUORESCENT PENETRANT

Technical Data Sheet

Description: **FP-22B** is a level 2, Method B & D non-water washable fluorescent penetrant for inspecting castings, extrusions and similar parts. **FP-22B** is a versatile, general purpose penetrant for use on a variety of materials, including aluminum and magnesium. Complies with low sulfur and low halogen requirements.

Chemical Properties

Color: Green
Viscosity: 4.94 cSt @ 100°F
Fluorescence: Yellow/Green
Flash Point: 225°F (107.2°C)

Companion Products

D-90G Dry Powder Developer	D-110A Water Suspensible Developer
D-100 Non-Aqueous Developer	DR-60 Solvent Remover
D-106 Non-Aqueous Developer	DR-62 Solvent Remover
D-113G Water Soluble Developer	ER-83A Hydrophilic Emulsifier
ER-85 Lipophilic Emulsifier	

Packaging

One Gallon Cans 55 Gallon Drums
Five Gallon Cans

Storage /Shelf Life

Keep away from moisture and sunlight.
Temperature limit: 40°F to 125°F (0-50°C)
Keep the container closed when not in use.
Shelf life from invoice date: Bulk Container – 5 Years

Specifications

SAE AMS 2644 & QPL – Type 1, Method B & D, Level 2	
MIL-I-25135 Revisions D & E	ASME Code NDT, Sec V
Lockheed Martin	Boeing
Rolls Royce	Honeywell
Turbomeca	Airbus
General Electric	Northrop Grumman



Special Features

1. Low to near zero background for assured indication visibility.
2. Sharp, precise flaw indication for rapid interpretation.
3. Excellent electrostatic spray capability.
4. Long material tank life due to formula stability and non-volatility.
5. Low material consumption (low drag out) due to low viscosity.
6. Clean, odorless product, vapor free atmosphere.

Instructions

Note: These instructions describe the basic process, but they may need to be amended by the user to comply with applicable specification and/or inspection criteria provided by the contracting agency.

1. **Application:** Apply **FP-22B** only to clean, dry surfaces by spraying, flowing, brushing or dipping.
2. **Dwell Time:** A 10 minute dwell time is suggested, although in many cases five minutes will suffice. When particularly tight cracks are suspected, or the part is especially critical, the dwell time may be extended to 30 minutes, or longer. Allow the penetrant to drain from the part surface back into the penetrant tank to conserve material.
3. **Removal:**
 - A) Hydrophilic Dip Method**
 - a) Pre wash: Following the dwell, use a plain water rinse to remove most of the undrained penetrant from the surface. Use a coarse spray of ambient temperature water.
 - b) Immersion: Immerse and agitate the part in 20-30% hydrophilic emulsifier solution. Immersion time and agitation time will vary with part geometry and surface condition.
 - c) Rinse: Remove the part from the tank; clean with a coarse, plain water spray.
 - B) Hydrophilic Spray Method**
 - a) Wash: Following the dwell, use an injection of 0.1 to 5.0% emulsifier solution to wash the excess penetrant from the part surface. Time and solution concentrations will vary with part geometry and surface conditions.
 - b) Rinse: Use a coarse plain water spray to remove all traces of the emulsified penetrant.
 - C) Lipophilic Method**
 - a) Emulsification: Following the dwell, dip the part into undiluted lipophilic emulsifier. Remove the part and allow the excess emulsifier to drain back into the tank. Parts with rough surfaces require longer drain times.
 - b) Rinse: Use a coarse plain water spray to remove all traces of the emulsified penetrant.
4. **Drying:** A re-circulating oven set no higher than 160°F (71°C) is suggested. Leave the part in the oven just long enough to evaporate surface moisture. Drying is improved by using pressurized air to disperse and remove as much excess water as possible before placing the part in to the oven.



5. **Developing:** Apply the developer by cloud, dusting spray or dip using the appropriate developer. Flaw marks are visible under black light almost immediately, but allow sufficient developing time to enhance the flaw visibility.

6. **Inspection:** Inspect parts under appropriate UV-A light intensity and minimal visible light.

Health & Safety

FB-22B is a combustible liquid. Use with adequate ventilation and away from sparks, fire or open flames. Avoid prolonged or repeated contact with skin. Do not take internally. Consult the MSDS for more safety and health information.